

## Fits 9" Round Column, Hi-Visibility Column Protector with Reflective Straps, Orange - 1709OR

### Product Images

---



## Short Description

---

Eagle 9" Column Protectors (42" high) offer affordable protection for warehouse and factory columns and beams (for 9" round columns).

## Description

---

Eagle 9" Column Protectors (42" high) offer affordable protection for warehouse and factory columns and beams (for 9" round columns). Absorbs impact from tow motors, minimizing column, fork truck, and personnel damage and injury. These orange blow-molded 100 percent high-density polyethylene (HDPE) protectors are resistant to most chemicals and feature key-lock to prevent slippage and assist with installation alignment. No tools required. Two halves attach with easy-to-install reflective straps (included).

## Specifications

---

Model No	1709OR
Color	Orange
Dimensions, Exterior	24D x 42H
Dimensions, Interior	9" (22.9 cm.) - Round
UPC	48441004249
Fits Column Size	9" Column
Material Specifications	High-Density-Polyethylene
Pallet Quantity	8
Net Weight, lbs	40
Net Weight, kgs	18.14