

# 40 Gallon, 3 Shelves, 2 Doors, Sliding Self-Close, Paint Safety Cabinet, Red - PI30X

## Product Images



## Short Description

- Reinforced double wall construction with 1-1/2 in (3.8 cm) air space on sides, top, bottom, back and doors
- Constructed of 18-gauge steel
- Lead-free, high-gloss, baked-on powder finish
- Continuous piano hinges
- Ground connection

- Four adjustable galvanized leveling legs
- Trilingual warning labels
- 2 in (5.1 cm) raised leakproof sill
- Patented adjustable galvanized steel shelves direct spills to back and bottom of leakproof sump and hold 350 lbs. (158.8 kg) Uniform Distributed Load (UDL)
- Internal and external welded construction
- Two 2 in (5.1 cm) internal vents with fire baffle and cap
- Flush mounted door handle with key lock
- Three-point stainless steel bullet latching system
- 3 in (7.6 cm) centers for shelf brackets
- Self-latching doors
- Door closings: Self-Closing (90° opening)
- Concealed self-close mechanism provides obstruction-free access to top shelf space
- Self-indexing doors guarantee they will close in sequence and ensure a tight closure from top to bottom

## Description

---

Eagle 40 Gallon, sliding self-close, Paint and Ink Safety Cabinets come with additional shelves to maximize storage space. Constructed of 18-gauge (1 mm) steel, the sides, top, bottom, and doors are double-walled with a 1-1/2 in (3.8 cm) air space between walls. Includes two vents, each have 2 in (5.1 cm) threaded fittings and a fire baffle and cap. Cabinets have a high gloss powder coat finish with red trilingual warning, plus grounding attachment, 3-point latch system, and 2-in (5.1 cm) raised, leakproof door sill. Each shelf is adjustable on 3 in (7.6 cm) centers, supported by 4 brackets, with a 350 lbs (159 kg) safe allowable load. Cabinets are FM-Approved and meet NFPA Code 30 and OSHA requirements.

## Specifications

---

Model No	PI30X
Color	Red
Material Specifications	18-Gauge Steel
FM Approval	Yes
OSHA Compliance	Yes
Complies with NFPA Code 30	Yes
Door Style	Bi-Fold
UPC	048441691289
Dimensions, Exterior	43W x 18Dx 44H
Dimensions, Interior	39.5" W x 14.56" D x 39.5" H (100.3 x 37 x 100.3 cm)
Number of Doors	1
Number of Shelves	3
Uniform Fire Code	Yes
Lock	Yes
Gallon Capacity	40
Liter Capacity	151.42
Replacement Shelf Model No.	29937
Pallet Quantity	1
Shelf Depth	14" (35.6 cm)
Net Weight, lbs	236
Net Weight, kgs	107.05
Adjustable Shelf	Yes

## Prop 65

---

 **WARNING:** This product can expose you to chemicals including Lead, which is known to the State of

California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).