

5 Gallon, 5/8" Metal Hose, DOT Transport Type II Safety Can for Diesel, Yellow - 1215SX5Y

Product Images



Short Description

- Reduce the danger of explosion while dispensing flammable liquids through a flexible metal spout
- Have double-walled flame arrestors in filler opening and pour spout
- Heavy duty roll bars protect both spouts, and a thumb screw mechanism assures the filler opening stays closed while being transported
- Meet DOT requirements

Description

Type II Safety Cans are made of 24 gauge galvanized steel and help reduce the danger of explosion while dispensing flammable liquids thru a flexible 12" metal spout. This design features two openings, one with a pressure-relief spring closing lid for filling, one with an actuated pour valve with a flexible metal spout for safer controlled dispensing. The filler spout and flame arrestors in both openings are non-sparking designed for flashback protection. Can includes a 5/8" flexible metal spout and a yellow (for diesel) powder coat finish FM, UL, and ULC Approved and meet OSHA and NFPA Code 30 requirements.

Specifications

Model No	1215SX5Y
Color	Yellow
UPC	048441004973
Hose Dimensions, inches	5/8" x 12"
Metal Hose	5/8"
Gallon Capacity	5
Material Specifications	24-Gauge Galvanized Steel
Dimensions, Exterior	12.5D x 15.75H
Pallet Quantity	64
Net Weight, lbs	13
Net Weight, kgs	5.9
OSHA Compliance	Yes
Complies with NFPA Code 30	Yes

Prop 65

⚠️WARNING: This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.