

8 Quart, Steel Bench Can, Dasher Screen, Red - B608

Product Images



Short Description

- Constructed of galvanized steel with a red baked on powder coat finish
- 8 quart capacity

Description

Safety Bench Cans are constructed of galvanized steel with a red baked on powder coat finish. With a 8 quart capacity (B608) this can is designed for safer cleaning of small parts or swabbing of larger ones. Features a brass flame arrestor dasher screen and pump assemblies. When the dasher plate is pushed down, the safety can dispenses a small amount of liquid to easily moisten sponges or rags without messy or dangerous spills. FM approved and meet OSHA standards.

Specifications

| | |
|-------------------------|---------------------------|
| Model No | B608 |
| Color | Red |
| UPC | 048441223619 |
| Gallon Capacity | 2 |
| Liter Capacity | 7.57 |
| Material Specifications | 24-Gauge Galvanized Steel |
| Dimensions, Exterior | 11.25D x 7H |
| Pallet Quantity | 64 |
| Net Weight, lbs | 8.25 |
| Net Weight, kgs | 3.74 |
| FM Approval | Yes |
| OSHA Compliance | Yes |