
6 Quart, Steel Bench Can, Dasher Screen with Lid, Red - B606

Product Images





Short Description

- Constructed of galvanized steel with a red baked on powder coat finish
- 6 quart capacity
- Includes a lid

Description

Safety Bench Cans are constructed of galvanized steel with a red baked on powder coat finish. With a 6 quart capacity (B606) this can is designed for safer cleaning of small parts or swabbing of larger ones. Features a brass flame arrestor dasher screen and pump assemblies. When the dasher plate is pushed down, the safety can dispenses a small amount of liquid to easily moisten sponges or rags without messy or dangerous spills. FM approved and meet OSHA standards.

Specifications

Model No	B606
Color	Red
UPC	48441223503
Gallon Capacity	1.5
Liter Capacity	5.68
Material Specifications	24-Gauge Galvanized Steel
Dimensions, Exterior	7.75D x 9.5H
Pallet Quantity	50
Net Weight, lbs	3.67
Net Weight, kgs	1.66
FM Approval	Yes
OSHA Compliance	Yes