

# 1 Quart, Steel Bench Can, Dasher Screen, Red - B601

## Product Images

---



## Short Description

---

- Constructed of galvanized steel with a red baked on powder coat finish
- 1 quart capacity

## Description

---

Safety Bench Cans are constructed of galvanized steel with a red baked on powder coat finish. With a 1 quart

capacity this can (B601) is designed for safer cleaning of small parts or swabbing of larger ones. Features a brass flame arrestor dasher screen and pump assemblies. When the dasher plate is pushed down, the safety can dispenses a small amount of liquid to easily moisten sponges or rags without messy or dangerous spills. FM approved and meet OSHA standards.

## Specifications

---

Model No	B601
Color	Red
UPC	048441223213
Gallon Capacity	0.25
Liter Capacity	0.95
Material Specifications	24-Gauge Galvanized Steel
Dimensions, Exterior	6.25D x 3.625H
Pallet Quantity	100
Net Weight, lbs	2.17
Net Weight, kgs	0.98
FM Approval	Yes
OSHA Compliance	Yes