



## 2 Quart Steel Safety Can for Flammables, Type I, Flame Arrester, Red - UI4S

### Product Images



## Short Description

---

- Holds 2 quarts (1.9 l) of flammable liquid
- Seamless, 24-gauge, hot dip, galvanized steel construction
- Self-closing, leak-tested lid prevents spills
- Non-sparking flame arrester protects against explosions
- Can dimensions of 5.3125 in H x 9 in OD (13.5 cm H x 22.9 cm OD)
- Complies with OSHA, NFPA and CARB; UL-listed and FM-approved

## Description

---

The rugged and reliable 2 quart (1.9 l) Eagle Red Type I Steel Safety Can for Flammables (model UI4S) weighs 2.25 lbs. (1.1 kg) when empty and roughly 6 lbs (3 kg) when full, making it great for quick fuel ups. The pour or fill hole has an inner diameter of 1.65 in (4.19 cm), and because this can measures 5.3125 inches (13.5 cm) high with an outer diameter of 9 inches (22.9 cm), it's easy to store in your Eagle safety cabinet.

You can also add an optional funnel to prevent spills and splashes when pouring into smaller tanks.

## Why use Eagle Type I safety cans?

Prevent fires and explosions by controlling flammable vapors with Eagle heavy-duty Type I safety cans. Our metal safety cans are 100 percent American-made and provide a safe and convenient way to carry, pour and store flammable liquid or fuel.

All Eagle Type I safety cans are accepted under CARB, meet OSHA and NFPA Code 30 requirements, are UL and ULC-listed, and FM-approved for safe storage and handling of flammable liquids.

## Leak-tested, dependable engineering

The state-of-the-art engineering and 24-gauge, hot dip, galvanized steel construction of Eagle Type 1 safety gas cans means you never have to worry about spills or leaks at your facility again. Eagle cans are the only safety cans made using a unique, deep-drawn process that leaves no top or side seams, eliminating any risk of leaks. It also prevents a gas odor from escaping the can. Plus, the self-closing, leak-tested lid and double interlock, no-weld bottom seam safeguards against spills even if the can is dropped or knocked over.

A nitrile gasket automatically releases vapors between 3 and 5 psi internal pressure to prevent rupture. And the non-sparking flame arrester absorbs and dissipates heat, preventing possible ignition or explosion.

The comfort grip and trigger release handle allow for smooth pouring without putting unnecessary strain on your employees' wrists. Model UI4S also features a fixed steel handle for easy carrying, even when full.

In short, our commitment to engineering excellence results in a safety can you can depend on to keep your

facility and your team safe.

## Promotes clear communication

To minimize accidents and avoid confusion over contents, these durable Type I fuel cans are color-coded according to standard industry conventions (red = gasoline, yellow = diesel, blue = kerosene and green = oil). This allows personnel to swiftly identify and grab the can they need for the job.

All Eagle Type I safety cans come with a trilingual safety label in English, Spanish and French.

Make sure your operation keeps moving. Stock up on replacement parts, including [flame arresters](#) and [gaskets](#) from Eagle. And purchase an optional plastic [funnel](#) for easy pouring.

## Specifications

---

Model No	UI4S
Color	Red
UPC	48441221219
Gallon Capacity	0.5
Liter Capacity	1.89
Material Specifications	24-Gauge Galvanized Steel
Dimensions, Exterior	9D x 5.3125H
Pallet Quantity	160
Net Weight, lbs	2.25
Net Weight, kgs	1.02
FM Approval	Yes
UL Approval	Yes
ULC Approval	Yes
OSHA Compliance	Yes
Complies with NFPA Code 30	Yes
CARB Compliance	Yes

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).