

2.5 Gallon, 7/8" Metal Hose, Steel Safety Can for Flammables, Type II, Red - U226S

Product Images



Short Description

- 7/8" pouring hose
- 24-gauge hot dipped galvanized steel construction
- Spring closing lid for filling and a separate hose for accurate pouring
- Patented comfort grip
- Non-sparking flame arrester
- Baked on powder coat finish
- Double interlock, no-weld bottom seam
- Deep drawn construction means no top or side seams

Description

Eagle 2.5 Gallon Type-II Safety Can (U226S) feature two openings, one with a pressure-relief spring closing lid for filling, one with an actuated pour valve with a flexible metal spout for safer controlled dispensing. The filler spout and flame arrestors in both openings are non-sparking brass designed for flashback protection. Can includes a 7/8" flexible metal spout and a red (for gasoline and other flammable liquids) powder coat finish with a trilingual label. FM, UL, and ULC Approved and meet OSHA and NFPA Code 30 requirements. Compliance: OSHA 29 CFR 1910.106, 1925.152 and NFPA Code 30.

Specifications

Model No	U226S
Color	Red
UPC	048441221424
Hose Dimensions, inches	0.88
Metal Hose	7/8"
Gallon Capacity	2.5
Liter Capacity	9.46
Material Specifications	24-Gauge Galvanized Steel
Dimensions, Exterior	11.25D x 9.5H
Pallet Quantity	105
Net Weight, lbs	8
Net Weight, kgs	3.63
FM Approval	Yes
UL Approval	Yes
ULC Approval	Yes
OSHA Compliance	Yes
Complies with NFPA Code 30	Yes