

2 Quart Galvanized Steel Plunger Dispensing Can, Dasher Screen, Red - P702

Product Images



Short Description

Eagle 2 Quart Galvanized Steel Safety Plunger Can (P702) is ideal for cleaning with flammable or volatile fluids

Description

2 Quart Galvanized Steel Safety Plunger Can (P702) is ideal for cleaning with flammable or volatile fluids. This can features a brass flame arrestor dasher screens and brass pump assemblies and comply with OSHA standards. When the dasher plate is pushed down, the safety can dispenses a small amount of liquid to easily moisten sponges or rags without messy or dangerous spills. Galvanized body features a baked-on red powder coat finish. FM approved.

Specifications

Model No	P702
Color	Red
Brand	Eagle
UPC	48441224302
Gallon Capacity	0.5
Liter Capacity	1.89
Material Specifications	24-Gauge Galvanized Steel
Dimensions, Exterior	8D x 8.5H
Pallet Quantity	72
Net Weight, lbs	3
Net Weight, kgs	1.36
FM Approval	Yes
OSHA Compliance	Yes

Prop 65

⚠️WARNING: This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.