

# Bench Top Flammable Safety Cabinet

## Product Images







## Short Description

---

- **Benchtop Convenience:** Provides easy access to frequently used liquids while maintaining safety and compliance on countertops and workbenches
- **Durable Construction:** Built with sturdy 18-gauge steel double-walls and 1.5 inches of insulating air space for superior fire resistance
- **Spill Management:** Sturdy steel shelves direct spills to a leakproof sump for safety and compliance
- **Secure Closure:** Includes dual vents with flame arresters and available in manual closing or self-closing door options
- **Compliance and Warranty:** Meets NFPA and OSHA regulations, FM-approved, with a ten-year warranty for reliability
- **Versatile Options:** Available in five colors (yellow, red, gray, White, beige) and two capacities (2 and 4 gallons) to meet specific storage needs

## Description

---

Eagle bench top safety cabinets offer a versatile and safe way to store hazardous materials, such as flammable liquids, on workbenches or countertops. They can also easily be relocated to point of use. These cabinets are designed to provide easy access to frequently used liquids while maintaining a high level of safety and compliance with NFPA and OSHA regulations.

Constructed with sturdy 18-gauge steel double-walls and 1.5 inches of insulating air space, these cabinets provide superior fire resistance and durability. They feature adjustable galvanized steel shelves that direct spills to a leakproof sump, ensuring safety and compliance. The cabinets also include dual vents with fire baffles and a built-in grounding connector for added safety.

To configure your safety cabinet, select from various color options, including yellow for flammables, red for


combustibles, gray and White for waste storage, and beige for lab use. Choose from capacities of 2 or 4 gallons to meet your specific storage needs. Additionally, select between manual closing or self-closing doors to ensure compliance with your safety requirements. Self-closing doors are a critical safety feature in these cabinets, offering enhanced protection against fires and accidental releases. These doors automatically close and latch in the event of a fire or emergency, minimizing human error by ensuring that the cabinet is always properly closed.

Eagle safety cabinets are designed to meet the complex requirements of handling and storing hazardous materials, providing a reliable solution for industries such as laboratories, manufacturing, and chemical processing plants. By configuring your cabinet, you ensure a safe and compliant storage solution tailored to your unique needs. All Eagle cabinets meet NFPA Code 30 and OSHA requirements, ensuring peace of mind and reliable performance.

## Specifications

Model No	1900BTOP
----------	----------

## Prop 65

 **WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## Product Options

Color:	Red
	Yellow
	Gray
	Beige
	White
Capacity:	2 gallon
	4 gallon
Door Style:	Self-close
	Manual Close